15

20

25

[0003]

[0002]

# CONCENTRATED STOCK OF CAPSULES FOR DETERGENT OR PERSONAL CARE COMPOSITIONS

#### FIELD OF THE INVENTION

A stock composition, which can be pre-mixed or stored, for further use in detergent or personal care compositions, the stock comprising a high concentration of capsules which are desired for incorporation into the final consumer product.

#### BACKGROUND OF THE INVENTION

In many articles of commerce, particularly consumer products, it is desirable to separate certain ingredients, yet have them disposed in a common container. Separation is particularly beneficial where one or more ingredients have negative interactions with each other. For example, in laundry detergents, enzymes are useful in removing stains but it is also best to separate them from other constituents, such as sources of alkalinity and surfactants, especially anionic surfactants like linear alkylbenzene sulfonates or alkyl sulfates. Bleaches, vitamins, perfumes, vegetable oils, plant extracts and ceramides are further examples of ingredients that sometimes need to be separated from the rest of the detergent or personal care composition.

A known technique for separating ingredients in a common container includes encapsulation. Encapsulation technology is well known for different applications. Generally, encapsulation includes a medium that surrounds at least one component and thereby provides a barrier between the "encapsulated" component and other components. The barrier is typically temporary and is designed to break down and release the encapsulated material at a desired time, such as at a particular temperature, upon reaction or dissolution with chemicals, or due to mechanical stress. Methods of encapsulation include coacervation, liposome formation, granulation, coating, emulsification, atomization and spray-cooling.

10

15

20

[0005]

[0006]

[0004] See, for instance, the disclosures of enzyme encapsulates and encapsulation processes: Falholt et al. (U.S. Patent 4,906,396, UK 2,186 884, and EP 0 273 775), Tsaur et al. (U.S. Patents 5,434,069 and 5,441,660), Ratuiste et al. (U.S. Patent 5,589,370). JP 41003667 discloses a dialysis of a protein solution against polyol-base polymer. WO 01/05949 discloses a method for densifying enzyme capsules. See also Mitchnik et al. (U.S. Patent 5,733,531) and Leong (U.S. Patent 5,296,166).

It is also desirable in the manufacturing process to prepare a stock of capsules, so that the capsules may be shipped or stored. In order to prepare such stock, it is necessary to prevent capsule agglomeration after formation and on storage: known capsules frequently agglomerate due to tacky hydrophobic encapsulating materials at the capsule surface. The agglomeration problem is exacerbated when capsule concentration is increased in an attempt to prepare a concentrated stock of capsules.

#### SUMMARY OF THE INVENTION

The present invention includes concentrated stock composition of capsules for incorporation into detergent or personal care composition, the stock composition comprising a high concentration of capsules comprising a hydrophobic material for forming the capsules, and a supernatant comprising water and a high HLB surfactant and/or a superwetting agent.

[0007] The following detailed description and the examples illustrate some of the effects of the inventive compositions. The invention and the claims, however, are not limited to the following description and examples.

## DETAILED DESCRIPTION OF THE INVENTION

[0008] Except in the operating and comparative examples, or where otherwise explicitly indicated, all numbers in this description indicating amounts of material or conditions of reaction, physical properties of materials and/or use are to be understood as modified by the word "about." All amounts are by weight, unless otherwise specified.

20

25

30

[0014]

[0009] For the avoidance of doubt the word "comprising" is intended to mean including but not necessarily "consisting of" or "composed of". In other words the listed steps or options need not be exhaustive.

The term "continuous" does not necessarily mean "isotropic". The term "continuous" is used herein to denote the phase which is predominant in volume during emulsification or dispersion of discontinuous phase in the continuous phase.

10 [0011] The term "hydrocarbon oil" as used herein means a hydrocarbon oil having a maximum viscosity of about 10 kg/(m)(sec), preferably no greater than about 5 kg/(m)(sec).

[0012] The term "wax" as used herein means a hydrophobic material which is a solid at 20°C. By "solid" is meant the ingredient is not mobile at 20°C.

## **CAPSULES**

[0013] The inventive stock compositions comprise a high amount of capsules. The stock compositions may be conveniently stored or shipped. The problem of agglomeration is avoided due to the presence in a supernatant part of the composition of a high HLB surfactant and/or super-wetting agent.

The capsules are formed of a hydrophobic material such as, for example, paraffin, oil, wax or petroleum jelly ("petrolatum"), a polymer, and mixtures thereof. However, it is within the scope of the present disclosure that other suitable materials can be used as the shell material. The desired ingredient for the encapsulation may form a continuous phase with the hydrophobic material (it can then be co-melted with the hydrophobic material) or it may form a discontinuous phase. In the latter case, the hydrophobic material forms a continuous phase, which surrounds a discontinuous phase. A hybrid of the two cases is also possible, i.e. both the continuous and discontinuous phases contain benefit ingredient(s) and/ or colorant(s).

[0015]

5

10

15

20

25

30

[0016]

In one preferred embodiment of the invention, a mixture of a thermoplastic block co-polymer and a hydrocarbon oil is employed as the hydrophobic material, particularly when it is desired to make transparent capsules. The block co-polymers particularly suitable in the present invention are block copolymers containing at least one rigid block and at least one flexible block. The mixture of the hydrocarbon oil and the block co-polymer according to the present invention is isotropic at 20°C. It should be understood that since the co-polymer is not pourable at 20°C (indeed, it is solid), it may be difficult to combine the co-polymer with the oil at such temperature to ascertain whether the mixture is isotropic. According to the present invention, a mixture may be formed at any suitable temperature at which the liquefied co-polymer forms an isotropic liquid mixture with the oil. The copolymer/oil mixtures suitable for use in the present invention, however, remain isotropic after cooling. Suitable isotropic mixtures have transmittance of at least 50%, preferably at least 70% as measured by UV-visible spectrophotometer (measured in the visible light range).

# Block Co-polymer

In one embodiment of the invention, the co-polymer employed for forming the capsules is selected from the group consisting of a triblock co-polymer, radial co-polymer, and multiblock co-polymer, the co-polymer comprising at least one triblock with a structure: rigid block---flexible block---rigid block. Preferably the rigid block is styrene-type polymer, and the flexible block is rubber-type polymer. By virtue of employing the rigid-flexible-rigid block co-polymer, the viscosity of the oil is increased, and the hardened capsule is formed, yet the resulting capsule is sufficiently soft and friable to release the benefit ingredient in normal use. The co-polymer blends uniformly with oil at a temperature which is much lower than the melting point of wax, thus allowing for encapsulation of temperature-sensitive ingredients, e.g. bleach, perfume, enzyme, vegetable oil, etc.

[0017] The preferred co-polymers are transparent and uncolored, in order to attain a transparent and uncolored continuous phase.

[0018] Examples of suitable co-polymers include but are not limited to those that are described in Morrison et al. (U.S. Patent 5,879,694) hereby incorporated by reference herein.

Each of the triblock, radial block and/or multiblock copolymers in the invention contains at least two thermodynamically incompatible segments. By the expression thermodynamically incompatible with respect to the polymers, it is meant that the polymer contains at least two incompatible segments, for example at least one hard and one soft segment. In general, in a triblock polymer, the ratio of segments is one hard, one soft, one hard or an A-B-A copolymer. The multiblock and radial block copolymers can contain any combination of hard and soft segments, provided that there are both hard and soft characteristics. In the optional diblock copolymer, the blocks are sequential with respect to hard and soft segments.

15

[0020]

Commercially available thermoplastic rubber type polymers which are especially useful in forming the capsules of the present invention are sold under the trademark Kraton® by Shell Chemical Company. The Kraton® rubber polymers are described as elastomers which have an unusual combination of high strength and low viscosity and a unique molecular structure of linear diblock, triblock and radial copolymers. Each molecule of the Kraton® rubber is said to consist of block segments of styrene monomer units and rubber monomer and/or comonomer units. Each block segment may consist of 100 or more monomer or comonomer units. The most common structure is the linear ABA block type; styrene-butadiene-styrene (SBS) and styrene-isoprene-styrene (SIS), which is the Kraton® D rubber series.

25

30

20

[0021] A second generation polymer of this general type is the Kraton® G series. This copolymer comprises a styrene-ethylene-butylene- styrene type (S-EB-S) structure. The Kraton® G series is preferred in the practice of the invention, as the copolymers of this series are hydrogenated and thus more thermally stable; that is, decomposition is less likely to occur during blending of the G series polymers with the oil (the D series polymers having unsaturation within the

rubber block). The Kraton® G rubbers are indicated as being compatible with paraffinic and naphthenic oils and the triblock copolymers are reported as taking up more than 20 times their weight in oil to make a product which can vary in consistency from a "Jello®" to a strong elastic rubbery material depending on the grade and concentration of the rubber.

[0022] The optionally blended diblock polymers include the AB type such as styreneethylenepropylene (S-EP) and styrene-ethylenebutylene (S-EB), styrenebutadiene (SB) and styrene-isoprene (SI).

10

15

5

[0023] Preferably, when Kraton® series block co-polymers are employed (i.e., styrene-elastomer block co-polymers), the oil is essentially free of silicone-containing oils, in order to obtain optimum isotropic mixtures. By "essentially free" is meant that in the Kraton®/oil mixture, the amount of silicone-containing oil is preferably less than 2%, by weight of the continuous phase, more preferably less than 1%, most preferably less than 0.5% and optimally is 0%.

[**0024**]

The preferred polymer is a triblock polymer of the Kraton® G type, in particular Kraton® G-1650. Kraton® G-1650 is an SEBS triblock copolymer which has a specific gravity of about 0.91, and is said to have a tensile strength of about 3.45 newton/m2 as measured by ASTM method D-412-tensile jaw tester separation speed 25.4 cm/min. The styrene to rubber content of Kraton® G-1650 is said by the manufacturer to be about 29:71, and the Brookfield viscosity is about 8 kg/(m)(sec)(toluene solution, at 25°C, 25%w). The Shore A hardness is about 75.

[0025]

25

30

For making the transparent capsules, preferably a mixture of Kraton® 1650 with Kraton®1702 is employed, even though Kraton®1650 is sufficient on its own. The mixture may be preferred in some cases, in order to increase the friability of the capsules, while preserving transparency.

10

15

20

[0026] In a second embodiment of the invention, the diblock co-polymer may be employed (having rigid-flexible blocks), even in the absence of a triblock or radial co-polymer. Kraton® 1702 is a diblock co-polymer (styrene-ethylene/propylene). The properties of Kraton® 1702 make it more suitable for use as a viscosity modifier in making the emulsion. According to the second embodiment of the invention, when using Kraton® 1702, in the absence of other copolymers, a hydrophobic solid is added, in order to form capsules. Kraton® 1650, on the other hand, forms a gel, when mixed with oil. When using the mixture of two Kraton polymers, the weight ratio of Kraton® 1650 to Kraton® 1702 is generally from 1:10 to 10:1, more preferably from 3:1 to 7:1, most preferably from 2:1 to 5:1, and optimally from 1:1 to 4:1.

[0027] The block co-polymer is employed in the inventive process generally in an amount of from 0.1% to 15%, more preferably from 0.5% to 10%, most preferably from 0.5% to 7%, and optimally from 1% to 4%, by weight of the capsule or by weight of the continuous phase, if the discontinuous phase is present.

[0028] In another preferred embodiment, a mixture of oil and wax is employed. In yet another preferred embodiment, a mixture oil, wax, and the block copolymer is employed.

[0029] Natural or synthetic hydrocarbon oil or mixtures thereof may be employed.

Generally, the hydrocarbon oil may be a paraffinic oil, a naphthenic oil, natural mineral oil or the like. Examples include but are not limited to mineral oil, castor oil, vegetable oil, corn oil, peanut oil, jojoba oil, 2-ethylhexyl oxystearate (and other alkyl oxystearates), acetylated lanolin alcohol, alkyl palmitates such as isopropyl palmitate, 2-ethylhexyl palmitate, glycerol triacetates, disopropyl adipate, dioctyl adipate (and other alkyl adipates), isopropyl myristate, C12 to C15 alcohol benzoates, and the like.

[0030] Most preferably, the oil is mineral oil, because it is both economic and most compatible with the block co-polymer.

[0031] A preferred ingredient, in order to strengthen the capsules, is a hydrophobic solid. It should be noted, however, that the addition of a hydrophobic solid is not preferred, if transparent capsules are desired. Examples of suitable hydrophobic solids include, but are not limited to wax, microcystalline wax, fatty acid, hydrophobic silica, pigment (e.g., titanium dioxide), fatty alcohols, thermoplastic homo-polymers (preferably, polymers with melting point less than 95°C, to prevent boiling-out of the aqueous phase) such as polyethylene, polypropylene, and mixtures thereof.

Preferably, the hydrophobic solid is selected from paraffin wax, beeswax micro-crystalline wax, polyethylene, polypropylene, most preferably paraffin wax or beeswax, due to their low price and easy processability.

[0033] The capsule, or the continuous phase (if the discontinuous phase is present), generally includes from 0.1% to 60%, more preferably from 5% to 60%, most preferably from 10% to 40%, and optimally from 30% to 35% of the hydrophobic solid, in order to achieve the best balance between the strength of the capsules and their friability in use (% by weight of the total continuous phase).

20

25

[0034]

15

The continuous phase may include a surfactant as an emulsifier. Suitable surfactants are low HLB surfactants, which may be anionic, cationic, amphoteric, and nonionic, preferably having an HLB of 1 to 10, more preferably from 2 to 7 and most preferably less than 5. In a most preferred embodiment, the surfactant is Neodol® 25-3 available from Shell Chemical Co. The continuous phase generally includes from 0 to 10% of a surfactant, more preferably from 0.1 to 5%, most preferably from 0.3 to 4%, and optimally from 0.5% to 3%, in order to form an emulsion, yet to avoid the formation of a reverse emulsion (% by weight of the total continuous phase).

30

[0035] The discontinuous phase may be present in an amount of from 0.01 to 45%, more preferably from 5 to 45%, most preferably from 10 to 40%, and optimally from 20 to 35%, (% by volume of the capsule) in order to deliver

10

15

20

25

30

[0038]

[0039]

[0037]

sufficient benefit agent/colorant, provide an adequate protection for the benefit agent/colorant and to maintain the ease of processing.

[0036] For capsules which contain a discontinuous phase, the continuous phase may sometimes be referred to hereinafter as a "shell" or "shell material".

For simplicity, the material encapsulated within the shell, either directly, or as a discontinuous phase, will be referred to as an "enzyme". However, it is within the scope of the present disclosure that materials other than enzymes can be encapsulated by the techniques disclosed herein. These materials include, without limitation, perfumes, vitamins, colorants, anti-oxidants, UV protectors, functional polymers, dye fixatives, anti-wrinkle compounds, color safe and chlorine bleaches, softeners, anti-static agents, deodorant compounds, anti-foam agents, moisturizers, anti-bacterial agents and other useful compounds.

The discontinuous phase is selected from the group consisting of an oil, oil solution, an aqueous solution or a solid. In some instances, the discontinuous phase may itself be the desired ingredient and/or colorant. In other instances, the discontinuous phase serves as a vehicle for a benefit agent/colorant. More than one discontinuous phase may be present.

In the case of an enzyme, the discontinuous phase is an aqueous solution of the enzyme. The aqueous enzyme solution may optionally contain a low HLB surfactant, in order to further enhance the formation of the emulsion. If present, the surfactant may be chosen from and employed in the same amounts as the surfactants described above for the continuous phase. The level of the surfactant can be reduced or even eliminated, particularly if suitable agitation is used. Furthermore, the need for surfactant is entirely eliminated if the shell material is a mixture of thermoplastic polymer with oil, rather than a wax/oil mixture.

[0040] If the encapsulated material is an enzyme, the preferred enzymes include proteases, lipases, cellulase, amylase, bleaching enzymes and the like. When selecting enzymes for a liquid detergent system, the most preferred enzymes include proteases and cellulases.

5

[0041] Most preferably, the capsule contains both the benefit agent and the colorant, within a transparent shell, to provide a visual signal to the consumer that a composition contains an additional beneficial ingredient.

10

## Capsule Shape and Size

[0042]

The preferred capsules are substantially spherical, particularly, when incorporated into transparent composition and/or transparent package, in order to provide a pleasing, commercially attractive appearance. Other shapes, however, such as star, disk, square and oval, are possible.

15

[0043] The size of the capsules is such as to render them suitable for incorporation into detergent or personal care compositions. Typical size range is from 300μm to 5,000μm, more preferably from 500μm to 3,000μm, most preferably from 800μm to 1,600μm, to provide visibility while ensuring uniform suspension.

20

[0044] The capsules are present in the concentrated stock compositions of the invention generally in an amount of at least 20%, more preferably from 20 to 50%, most preferably from 20 to 45%, and optimally from 25 to 35%, by volume of the stock composition, in order to attain the concentrated stock, and yet to avoid flocculation.

25

#### PREPARATION OF CAPSULES

[**0045**]

The capsules for the stock composition of the invention may be prepared by any known encapsulation processes. Preferably, however, the capsules are prepared by the following process. This process is preferred because it avoids the capsules' agglomeration during the process.

[0046] The preferred process comprises immersing droplets of an emulsion or a dispersion containing the continuous and discontinuous phases into an aqueous curing solution containing a high HLB surfactant and/or a superwetting agent.

5

In the first step of the inventive process, an emulsion or dispersion is prepared by mixing the continuous and discontinuous phases, the latter being or containing the ingredient to be encapsulated, e.g. bleach solution or a vegetable oil. In the preferred embodiment, the co-polymer is melted, mixed with oil, then the discontinuous phase is added, with stirring (agitation), to ensure uniform mixing of the ingredients. The resulting emulsion/dispersion is preferably kept at a temperature in the range from 40°C to 95°C. Most preferably, the use of direct heat is avoided. A most preferred temperature range is from 60°C to 75°C.

15

[0048]

10

The resulting emulsion/dispersion is directed, either as a stream, or dripping, into the curing solution containing a surfactant agent with a relatively high HLB value and/or a super-wetting agent, whereby the discrete capsules are formed. Optionally, pressure may be employed in ejecting the stream, in order to ensure that the stream penetrates the surface of the curing solution. The curing solution may also be chilled, stirred, and/or pressurized. The curing solution is prepared by combining water and at least one surfactant with a high HLB value and/or a super-wetting agent.

20

The surfactants for the curing solution are selected from the group consisting of high HLB (7 to 25, preferably 10 to 20, most preferably 12 to 16) surfactants, preferably linear and branched nonionic such as Neodol® 25-12, 12-9 and Tergitol® 15-S-9. In a most preferred embodiment, the surfactant is Neodol® 25-12, which has a carbon chain length between 12 and 15, with 12 ethylene oxide groups per molecule.

10

15

[0050] The surface tension modifying agent or super-wetting agent is a highly efficient, low surface energy surfactant. Examples of super-wetting agents are as follows:

Super-wetting Agent	Supplier	Chemical
		Description
Zonyl®FSO	duPont	Fluoro chemical with ethylene glycol
Fluorad®	3MCompany	Fluorinated alkyl alkoxylate
DC Q2	Dow Corning	Polyoxy ethylene modified
		polydimethyl siloxane
Tergitol® 15-S	Union Carbide	Mixture of linear secondary alcohols
		reacted with ethyleneoxide
Surfynol® TG	Air Products &	2,4,7,9-teramethyl-5-decyne-4,7-diol
	Chemicals	
Makon® OP-9	Stepan Chemical	Octyl phenol with 9 moles of
		ethylene oxide
Fluowet OTN	Hoechst Celanese	Fluoroaliphatic oxyethylate
Silwet® L-77	Union Carbide	Polyalkylene oxide modified
		heptamethyltrisiloxane

[0051] The most preferred super-wetting agent is Silwet® L-77 due to its ready availability and optimum performance.

[0052] The constituents in the curing solution are preferably present in the following ranges: water, 60% to 99%, most preferably 80% to 95%; surfactant and/or a super-wetting agent, 1% to 40%, most preferably 5% to 15% (all by weight of the curing solution).

[0053] In the preferred embodiment, the curing solution comprises both the high HLB surfactant and the super-wetting agent.

[0054] The super-wetting agent is preferably added as a pre-diluted solution by dripping along, as close to the capsule formation as possible, so that the super-wetting agent is on the surface of the curing solution.

[0055] The preferred curing solution contains a super-wetting agent generally in an amount of from 0.1 to 40%, more preferably from 1 to 20%, most preferably

[0057]

10

15

25

30

from 2 to 10%, and optimally from 3 to 7% (% by weight of the curing solution).

The curing solution is preferably kept at a temperature in the range from 0°C [0056] 5 to 50°C. A most preferred temperature range is from 10°C to 30°C.

> In one preferred embodiment, the emulsion/dispersion of the continuous and discontinuous phases is caused to flow (preferably, under pressure) to form a stream which is directed into the curing solution. The stream breaks up into capsules within the curing solution. The stream can be defined by temperature, velocity, width and distance from the upper surface of the curing solution. The size of the orifice through which the stream is directed and the pressure with which it is ejected will also affect the nature of the stream. In a preferred embodiment, the following operating parameters were found to produce capsules in the range of 200μm to 2500μm: emulsion temperature: 54-85°C; vessel pressure: 0-1.05 kg/cm2, most preferably 0.3-0.6 kg/cm2; nozzle distance from curing solution: 2.5-20cm, most preferably 17.5 cm; nozzle orifice diameter: 0.0125-0.25 cm; curing solution temperature: 0-50°C.

In an alternative preferred method for forming the capsules, the 20 [0058] emulsion/dispersion is delivered to the curing solution by a plurality of nozzles: the emulsion is allowed to drip under the static head or the pressure. The dripping forms capsules upon contact with the curing solution. The size of the nozzle openings and the height of the liquid in vessel ("static head") containing the emulsion and the distance from the curing solution all play a part in the ultimate size of capsules.

In each embodiment, the curing solution is continually agitated during the [0059] emulsion addition, in order to distribute the formed capsules and keep the surface in motion.

[0060] In each of the above processes, the droplets/capsules advantageously have a density greater than that of the curing solution. As such, the formed capsules

10

15

20

25

30

[0062]

fall to the bottom of the receiving vessel and do not interfere with new droplets/capsules as they contact the surface of curing solution. Preferably, the density of the capsules is at least 1.0, most preferably from 1.01 to 2. Suitable methods for increasing the density include, but are not limited to the addition of solid inorganic material, sugar, or any high density solute to the discontinuous phase of the emulsion.

[0061] Without being bound by theory, it is believed that the outer, hydrophobic surface of capsules attracts the hydrophobic portions of the surfactant molecules in the curing solution, thereby leaving the hydrophilic portions of the surfactant molecules extending from the outer surface of the capsules. Assuming this to be true, the capsules naturally repel each other due to hydrophilic molecule portions extending from the hydrophobic "shell". During processing this is advantageous because the capsules remain separate in solution.

In the final step of the process, the capsules are collected out of the curing solution. If the capsules have density higher that that of the curing solution (i.e., higher than the density of water), then the vessel holding the curing solution may have one or more openings in the bottom of the vessel, for the capsules to drain out. The vessel volume may be continuously made up with a fresh curing solution.

[0063] If the capsule density is lower than that of water, then the capsules may be collected off the top of the solution by floating the top of the solution off into a collection vessel. Again, the vessel volume may be continuously made up with a fresh curing solution. When this method of collection is employed, it is particularly important that the droplets penetrate the solution surface (e.g., the pressure is employed in forming droplets and/or a super-wetting agent is employed), so that the capsules are formed before the top layer of the curing solution is collected.

10

15

20

25

[0067]

# **SUPERNATANT**

[0064] The capsules are stored in the form of a concentrated stock solution, which generally includes water and a high HLB surfactant and/or a super-wetting agent. The surfactant and the super-wetting agent are selected from the high HLB surfactants and super-wetting agents described above in the Process section for the curing solution.

[0065] The supernatant is present in an amount of from 40% to 80%, more preferably from 45 to 75%, most preferably from 50 to 70%, and optimally from 55 to 65%, in order to attain sufficiently concentrated stock, yet to avoid problems with pumpability (% by volume of the total stock composition).

[0066] The amount of water in the supernatant is generally from 0.5 to 99.5%, more typically from 30 to 98%, preferably from 70 to 97, and optimally from 85% to 95%, in order to prevent the flocculation of the capsules (% by weight of supernatant).

The precise concentration of the high HLB surfactant and/or super-wetting agent depends on the capsule concentration and the process employed for making capsules. If the capsules are made by the preferred process described above, they already have a layer of the high HLB surfactant/super-wetting agent absorbed to/associated with the surface of the capsules. In principle, the concentration of the high HLB surfactant/super-wetting agent in the supernatant is such as to provide an excess of the high HLB surfactant/super-wetting agent, in order to maintain the layer on the surface of the capsules. If the surfactant/super-wetting agent is too high, however, a film may be formed on the surface of the stock composition—such film is disadvantageous since it serves as a binder for the capsules.

The supernatant generally includes from 0.5 to 50%, more preferably from 2 to 40%, most preferably from 3 to 30%, and optimally from 5 to 15%, of the high HLB surfactant and/or the super-wetting agent (% by weight of the total continuous phase).

10

15

20

[0069] The supernatant preferably includes both the high HLB surfactant and the super-wetting agent. If both are present than the ratio of the high HLB surfactant to the super-wetting agent is from 5:1 to 1:5, more preferably from 4:1 to 1:4, most preferably from 3:1 to 1:3, and optimally from 2:1 to 1:2, in order to provide sufficient anti-flocculation and to maintain lubrication of the capsules.

[0070] The stock composition may optionally include other detergent/personal care ingredients, so that it can merely be diluted for final use. Examples of such ingredients include, but are not limited to builders, anti-redeposition agents, fluorescent dyes, perfumes, soil-release polymers, colorant, enzymes, bleaches, etc.

[0071] If not immediately used for the manufacture of final compositions, concentrated stock solutions of capsules are typically stored or shipped at 20°C.

[0072] The following specific examples further illustrate the invention, but the invention is not limited thereto.

[0073] Suppliers and chemical description of the ingredients used in the examples are summarized in the following table:

Trade Name (if appropriate)	Chemical Name	Supplier
Bowax® 800	Petroleum, Hydrocarbon, Microcrystalline Wax	IGI
Kraton® 1650	Styrene-(ethylene-Butylene)-Styrene tri- block co-polymer	Shell
Kraton® 1702	Styrene-(Ethylene-Propylene) di-block co- polymer	Shell
Sorbitol	D-Glucitol	SPI Polyols
Neodol® 25-3	Nonionic surfactant: Alcohol Ethoxylate, C12-C15 3 Ethylene oxide groups HLB=7.8	Shell
Neodol® 25-9	Nonionic surfactant: Alcohol Ethoxylate, C12-C15	Shell

Neodol® 25-12 Nonionic surfactant: Alcohol Ethoxylate, C12-C15 12 Ethylene oxide groups HLB=14.4  Petrolatum Hydrocarbons Penreco Sandoz Chemicals  Titanium Oxide Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Protease Protease Protease Fee-30 Dipolyhydroxystearate Froelem. Protease Froelem. F		9 Ethylene oxide groups	
Alcohol Ethoxylate, C12-C15 12 Ethylene oxide groups HLB=14.4  Petrolatum Hydrocarbons Penreco Sandoz Chemicals Titanium Oxide Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16% Petroleum, Hydrocarbon, paraffin Wax IGI Vitamin C Cargill Corn Wet Milling Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific Mineral Oil Hydrocarbons Fischer Scientific 1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Protease Protease Protease Feg-30 Dipolyhydroxystearate Frotease Genencor Frotease Genencor Genencor		HLB=13.1	
12 Ethylene oxide groups HLB=14.4     Petrolatum	Neodol® 25-12	Nonionic surfactant:	Shell
Petrolatum Hydrocarbons Penreco Blue Dye Sandolan Blue E-HRL powder 120 Sandoz Chemicals Titanium Oxide Dupont Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16% IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific Mineral Oil Hydrocarbons Fischer Scientific 1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI CIGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Novo Nordisk Purafect® Protease Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate Properase® 1600 L Protease Genencor		Alcohol Ethoxylate, C12-C15	
Blue Dye  Sandolan Blue E-HRL powder 120  Sandoz Chemicals  Dupont  Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9  Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Silwet® L-77  Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax  Petroleum, Hydrocarbon, paraffin Wax  Vitamin C  Sodium Bicarbonate  Sodium Hydrogen Carbonate  Sodium Hydrocarbons  Fischer Scientific  Mineral Oil  Hydrocarbons  Sodium Hydrocarbon, paraffin Wax  IGI  IGI® 941 Wax  Petroleum, Hydrocarbon, paraffin Wax  Lipolase®  Lipase  Purafect®  Protease  Protease  Genencor International, Inc  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Protease  Genencor		12 Ethylene oxide groups HLB=14.4	
Titanium Oxide  Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Purafect® Protease  Chemicals Dupont Akzo Nobel  Akzo Nobel  Union Carbide OSI Specialties  OSI Specialties  Cargill Corn Wet Milling Fischer Scientific Fischer Scientific  IGI  GI  GI  GI  Nove Milling Fischer Scientific  Fischer Scientific  Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate Ficl Genencor	Petrolatum	Hydrocarbons	Penreco
Titanium Oxide Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Protease Foreneor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate Protease Genencor Protease Genencor	Blue Dye	Sandolan Blue E-HRL powder 120	Sandoz
Cationic surfactant: Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Protease Protease Protease Peg-30 Dipolyhydroxystearate Protease Fischer Cargill Corn Wet Milling Fischer Scientific IGI  Fischer Scientific  Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate Fici			Chemicals
Dihydrogenated Tallow Dimethyl Ammonium Chloride  Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI  IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Purafect® Protease Protease Peg-30 Dipolyhydroxystearate Protease Fischer Genencor International, Inc Properase® 1600 L Protease Genencor		Titanium Oxide	Dupont
Ammonium Chloride Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Silwet® L-77 Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI  IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI  Lipase Purafect® Protease Protease Feg-30 Dipolyhydroxystearate Fischer Genencor International, Inc Properase® 1600 L Protease Genencor		Cationic surfactant:	Akzo Nobel
Tergitol® 15 S-9 Nonionic surfactant: Alkyloxypolyethyleneoxyethanol  Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI  IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI  Lipase Novo Nordisk Purafect® Protease Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease		Dihydrogenated Tallow Dimethyl	
Alkyloxypolyethyleneoxyethanol  Silwet® L-77  Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax  Petroleum, Hydrocarbon, paraffin Wax  Vitamin C  Cargill Corn Wet Milling  Sodium Bicarbonate  Sodium Hydrogen Carbonate  Fischer Scientific  Mineral Oil  Hydrocarbons  Fischer Scientific  1218® Wax  Petroleum, Hydrocarbon, paraffin Wax  IGI  IGI® 941 Wax  Petroleum, Hydrocarbon, paraffin Wax  IGI  Lipolase®  Lipase  Novo Nordisk  Purafect®  Protease  Genencor International, Inc  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Protease  Genencor  Genencor		Ammonium Chloride	
Silwet® L-77  Polyalkylene oxide modified hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax  Petroleum, Hydrocarbon, paraffin Wax  Vitamin C  Cargill Corn Wet Milling  Sodium Bicarbonate  Sodium Hydrogen Carbonate  Fischer Scientific  Mineral Oil  Hydrocarbons  Fischer Scientific  1218® Wax  Petroleum, Hydrocarbon, paraffin Wax  IGI  IGI® 941 Wax  Petroleum, Hydrocarbon, paraffin Wax  Lipolase®  Purafect®  Protease  Protease  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Protease  Genencor  Genencor  International, Inc  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Genencor	Tergitol® 15 S-9	Nonionic surfactant:	Union Carbide
hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Novo Nordisk  Purafect® Protease Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor		Alkyloxypolyethyleneoxyethanol	
hertamethyltrisiloxane 84%, and Allyloxypolyethylene glycol methyl ether 16%  IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax IGI Vitamin C Cargill Corn Wet Milling  Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI Lipolase® Lipase Novo Nordisk  Purafect® Protease Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor	Silwet® L-77	Polyalkylene oxide modified	OSI Specialties
IGI® 1045 Wax Petroleum, Hydrocarbon, paraffin Wax Vitamin C Cargill Corn Wet Milling Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific Mineral Oil Hydrocarbons Fischer Scientific 1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Purafect® Protease Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate Fischer Scientific Scientific IGI IGI IGI IGI IGI IGI ICI Inc Genencor		hertamethyltrisiloxane 84%, and	
Petroleum, Hydrocarbon, paraffin Wax   IGI			
Vitamin C  Vitamin C  Cargill Corn  Wet Milling  Sodium Bicarbonate  Sodium Hydrogen Carbonate  Fischer  Scientific  Hydrocarbons  Fischer  Scientific  1218® Wax  Petroleum, Hydrocarbon, paraffin Wax  IGI  IGI® 941 Wax  Petroleum, Hydrocarbon, paraffin Wax  Lipase  Purafect®  Protease  Protease  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Fischer  Scientific  IGI  Genencor  International, Inc  Arlacel® P135  Peg-30 Dipolyhydroxystearate  Foenencor  Genencor  ICI  Properase® 1600 L  Protease  Genencor			
Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI Lipolase® Lipase Novo Nordisk Purafect® Protease Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor	IGI® 1045 Wax		IGI
Sodium Bicarbonate Sodium Hydrogen Carbonate Fischer Scientific  Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI  IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI  Lipolase® Lipase Novo Nordisk  Purafect® Protease Genencor  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI  Properase® 1600 L Protease Genencor		Vitamin C	Cargill Corn
Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI Lipolase® Lipase Novo Nordisk Purafect® Protease Genencor International, Inc  Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor			Wet Milling
Mineral Oil Hydrocarbons Fischer Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax IGI Lipolase® Lipase Novo Nordisk Purafect® Protease Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor	Sodium Bicarbonate	Sodium Hydrogen Carbonate	Fischer
Scientific  1218® Wax Petroleum, Hydrocarbon, paraffin Wax IGI  IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Purafect® Protease Protease  Arlacel® P135 Peg-30 Dipolyhydroxystearate Properase® 1600 L Protease  Genencor Genencor Genencor Genencor			Scientific
Petroleum, Hydrocarbon, paraffin Wax   IGI	Mineral Oil	Hydrocarbons	Fischer
IGI® 941 Wax Petroleum, Hydrocarbon, paraffin Wax Lipolase® Lipase Purafect® Protease Protease Arlacel® P135 Peg-30 Dipolyhydroxystearate Properase® 1600 L Protease Genencor International, Inc Genencor Genencor			Scientific
Lipolase® Lipase Novo Nordisk Purafect® Protease Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor			IGI
Purafect® Protease Genencor International, Inc Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor			
Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor		1	Novo Nordisk
Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor	Purafect®	Protease	Genencor
Arlacel® P135 Peg-30 Dipolyhydroxystearate ICI Properase® 1600 L Protease Genencor			International,
Properase® 1600 L Protease Genencor			Inc
		<u> </u>	ICI
lar	Properase® 1600 L	Protease	Genencor
International,			International,
Inc			Inc

## EXAMPLE 1

[0074] This example demonstrates the benefit of using Silwet® L77 in curing bath.

One of the problems with encapsulation has been stability especially with regard to enzyme stability. In many examples below, sorbitol has been substituted for enzymes due to their like densities and hydrophilic nature.

10

15

20

25

Capsule formulation:	
2% Kraton®1702	35%
Bowax® 800	20%
70% Sorbitol aqueous solution	45%

[0075] 2% Kraton® 1702 liquid gel was prepared by mixing 2 parts of Kraton® 1702 and 98 parts of mineral oil and heated to 76.7°C until the mixture became isotropic. 35 parts of this prepared 2% Kraton® 1702 gel was mixed with 20 parts of Bowax® 800 at 60°C and followed by mixing in 45 parts of 70% sorbitol aqueous solution to form an emulsion. This emulsion was used to form capsules in two different curing solutions: one (outside the scope of the invention) contained only water; the other (within the scope of the invention) contained 1% Silwet® L77 aqueous solution.

# [0076] Equipment used:

Re-circulating encapsulation unit powered by a peristaltic pump. Lightening mixer used to create movement in water bath so capsules don't land on one another.

#### [0077] Results:

- 1) Sprayed emulsion into bath consisting plain DI (distilled deionized) water (a process outside the scope of the present invention). Results were capsules that stuck to the side of the bath walls. Also, when capsules came in contact with one another they stuck together into one lump and could not be separated even after shaking. Thus, these capsules were not collected for a concentrated stock of capsules.
- 2) Sprayed emulsion into bath consisting of 1% Silwet® L 77 and 99% DI water (a process within the scope of the present invention). Results were capsules that were discrete in that they didn't stick together when they came in contact with one another.
- [0078] Excess curing solution was removed. 40g of capsules and 60g of curing solution were collected in a 237ml glass jar. The volume concentration of

capsules for this concentrated stock was slightly higher than 40%, because the density of capsules was slightly lower than 1. The capsules were contacting its neighboring capsules. After 24 hours at 20°C, these capsules were freely flowing after only a gentle shaking.

5

10

#### **EXAMPLE 2**

[0079]

An emulsion was prepared by mixing 200g of petrolatum and the mixture of 99g of 70 w/w% aqueous sorbitol solution and 1g of 0.1% blue dye aqueous solution at 60°C in a 500 ml beaker. A bow-tie shape of ring agitator was used for mixing at 250 rpm. 6g of Neodol® 25-3 were added to enhance the formation of the emulsion. Separately, a curing bath was prepared by mixing 150 g water and 6g of Neodol® 25-12. The capsules were made by dropping emulsion drop-wise into the curing bath by a pipette. The capsules were round in shape and blue in color with the average size of 3000 µm. No visible dye leakage was observed for 24 hours; therefore, these capsules were stable. The excess curing solution was removed from the collecting vessel. The volume concentration of the collected capsules was about 30%. Stirring by a spatula demonstrated that the capsules remained discrete.

15

20

#### **EXAMPLE 3**

[0800]

This example used a cationic surfactant (dihydrogenated tallow dimethyl ammonium chloride) in the process according to the invention, in place of Neodol® 25-3, as an emulsifying agent.

Capsule composition:	
Petrolatum	100 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	80 g
dihydrogenated tallow dimethyl ammonium chloride	9 g

25

[0081]

Dihydrogenated tallow dimethyl ammonium chloride was added to petrolatum at 60°C. Sorbitol was then added slowly to bath, so as not to solidify the other ingredients. After mixing for 45 minutes, the emulsion was added drop-wise into curing solution, the latter described in Example 2. Capsules collected in the bath retained structural integrity. The excess curing solution was removed

from the collecting vessel. The volume concentration of the collected capsules was about 30%. After 24 hours, there was no visible dye leakage. Stirring by a spatula demonstrated that the capsules remained discrete.

EXAMPLE 4

[0082] This example demonstrates the manipulation of capsule density.

[0083] An emulsion was made as follows:

Petrolatum	200 g
Titanium oxide	2 g
dihydrogenated tallow dimethyl ammonium chloride	20 g
70% Sorbitol aqueous solution	140 g

10

[0084]

5

Petrolatum was heated to 60°C, followed by the addition of titanium oxide for adding white color. Subsequently, the temperature was raised to 65.6°C. After the addition of the cationic surfactant, the temperature dropped. The temperature was raised again to 65.6°C, then sorbitol solution was added. Upon addition of sorbitol, temperature dropped to 46.1°C. Temperature was allowed to climb back to 68.3°C.

[0085]

15

After mixing for 45 minutes, the emulsion was added drop-wise into curing solution containing:

20

Water	950 g
Tergitol® 15-S-9	50 g

[0086] Capsules made from this emulsion did not sink.

[**0087**]

Additional 15g 70% sorbitol was added to the emulsion and re-tested. The capsules still floated. Another additional 25g of 70% sorbitol solution was added, thus bringing the total sorbitol level to 180g. When capsules were dropped into curing solution, they initially began to sink, followed by rising to the surface, then sank to the bottom and stayed. Additional 20g of sorbitol was added thus bringing the total sorbitol level to 200g. Capsules of this final

emulsion sank to the bottom and never floated to the surface. The quality of the capsules was the same, but the high density capsules were easier to process.

The capsules with high density were collected at the bottom of curing bath. Excess curing solution was removed. 80g of capsules and 120g of curing solution were collected in a 237 ml glass jar. The volume concentration of capsules for this concentrated stock was slightly less than 40%, because the density of the capsules was slightly higher than 1. The neighboring capsules were contacting each other. After 24 hours at 20°C, these capsules were freely flowing by a gentle shaking.

#### **EXAMPLE 5**

[0089]

15

20

The Examples above used a pipette to form capsules. This example utilized a dispenser, as an apparatus for making capsules. The dispenser was a metal vessel, attached to a support, with multiple pipette tips attached to the bottom. The vessel was also heat-traced and temperature controlled. An agitator was used to maintain a good emulsion inside the vessel. Beneath the vessel was a crystallizing dish; holding a curing solution, on a stirring plate with a stirring bar.

Capsule formulation	T
Petrolatum	220 g
dihydrogenated tallow dimethyl ammonium chloride	20 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	220 g
Curing solution	
Water	950 g
Tergitol® 15-S-9	50 g

[0090]

25

The emulsion was first prepared in a beaker. Petrolatum was added and heated to 65.6°C, followed by the addition of cationic and allowed to fully melt. Sorbitol was then added slowly so as not to reduce bath temperature. The emulsion was subjected to constant mixing and heating. The curing solution was prepared and added to the crystallizing dish and kept at slow agitation. The dispenser's pipette tips were adjusted to approximately 5.1 cm

from the surface of curing bath. After the dispenser was preheated, the emulsion was poured into it. Droplets were formed at a near constant rate from the pipette tips. Capsules sank to the bottom and remained spherical. With the naked eye, the capsules appeared to be within a very tight size distribution. The average capsule size was about 2800 to 3000  $\mu$ m and the yield was about 110 capsules per tip per minute.

[0091] A concentrated stock of capsules was collected as 35% volume concentration in curing solution. These capsules were freely flowing after 24 hours.

10

5

#### **EXAMPLE 6**

[0092] White capsules were prepared by using the dispenser described in Example 5.

The formulation was as follows:

Capsule formulation	
Petrolatum	200 g
dihydrogenated tallow dimethyl ammonium chloride	10 g
Titanium oxide	2 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	192 g
Neodol® 25-3	7 g
Curing solution	
Water	950 g
Neodol® 25-9	50 g

15

20

[0093]

The emulsion was prepared by adding petrolatum, cationic surfactant and titanium oxide to a beaker and heating to 65.6°C. Sorbitol and Neodol® 25-3 were slowly added. Capsules were then formed following the procedure described in Example 5. The capsules were collected at the bottom of curing bath dish and left there, closely packed. After 24 hours, capsules were examined: with slight agitation, capsules were separated into discrete capsules again. After agitation was stopped, all capsules sank to the bottom again. This indicates that these capsules were stable, because the capsules would float if there were any leakage (since the density of sorbitol is higher than that of water). A concentrated stock of capsules was collected as 30% volume

20

25

concentration in curing solution. These capsules were freely flowing after 24 hours.

#### **EXAMPLE 7**

It was noticed that short distance between tips and curing bath resulted in some capsules floating at the surface of curing bath. Capsules may take 3 to 30 seconds to penetrate the surface before sinking to the bottom. A possible explanation may be the high surface tension of the curing bath; the drops falling from a short distance may not be able to penetrate the curing solution surface.

Capsule formulation	
Petrolatum	200 g
dihydrogenated tallow dimethyl ammonium chloride	8 g
Titanium oxide	2 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	184 g
Neodol® 25-3	7 g
Curing solution	
Water	950 g
Tergitol® 15-S-9	50 g

[0095] The preparation followed the procedure described in Example 5. The pipette tips were set to 2.5 cm above the bath surface. Some capsules remained at the surface. After adding 5 droplets of Silwet® L77, the capsules all sank to the bottom.

[0096] Thus, it is preferable to employ a combination of a high HLB surfactant and a super-wetting agent in the curing solution, and to increase the kinetic energy of the droplets/stream, so that the droplets/stream can penetrate the surface of the curing solution and the capsules can be enveloped by a surfactant.

[0097] Capsules were stored in a supernatant composed of 5% Tergitol® 15-S-9 and 0.5% Silwet®L77. The volume concentration of capsules was about 30%. The capsules did not agglomerate on storage.

[0099]

5

10

EXAMPLE 8

[0098] Wax was added in this example to improve the strength of capsules.

Capsule formulation	
Petrolatum	220 g
IGI® 1045 wax	80 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	675 g
Arlacel® P135	15 g
Neodol® 25-3	15 g
Curing solution	
Water	940 g
Neodol® 25-9	50 g
Silwet® L77	10 g

The preparation was similar to Example 5. Petrolatum, wax and Arlacel® P135 were added together and heated to 68.3°C, followed by a slow addition of sorbitol/dye solution, while maintaining temperature at 68.3°C. After all the sorbitol had been added and well mixed, Neodol® 25-3 was added and allowed to mix for 45 minutes to ensure that it traveled to the emulsion interface. The temperature was then lowered to 62.8°C. The emulsion was then poured into the dispenser and capsules formed in the curing bath. The average capsule size was about 2500 µm. A concentrated stock of capsules was collected as 35% volume concentration in curing solution. The capsules did not agglomerate on storage. After 48 hours, the color of curing solution remained the same, indicating that the capsules were stable (no leakage of dye).

## **EXAMPLE 9**

[00100] In order to make much smaller capsules, a batch of formulation was prepared following the procedure described in Example 5.

Capsule formulation	
Petrolatum	220 g
IGI 1045 wax	220 g
99 parts of 70% sorbitol and 1 part of 0.1% blue dye	600 g
Arlacel®P135	10 g
Neodol® 25-3	20 g
Curing solution	
Water	940 g

20

10

15

20

Neodol® 25-9	50 g
Silwet® L77	10 g

[00101] Apparatus used for forming droplets was a heat traced recycling loop with a gear pump, a nozzle and a back-pressure valve. The nozzle used in this example was a zero degree straight stream nozzle. The gear pump and the back-pressure valve were used to control the flow rate and kinetic energy of the discharged stream. The stream broke apart upon hitting the surface of curing bath and formed capsules beneath the bath surface. The flow rate was controlled between 0.5 to 1.2 liter/minute. The entire flow rate range supplied sufficient kinetic energy to break the stream into small capsules upon hitting the bath surface. The capsule size distribution was narrow between 300 to 600 microns. This example illustrates that capsule size may be controlled by controlling the kinetic energy of the discharged steam/droplets of the emulsion. Due to the small size of particles, a concentrated stock of capsules was collected as 30% volume concentration in a fresh curing solution.

**EXAMPLE 10** 

[00102] Vitamin C is a beneficial agent commonly used in personal care products. It is a strong anti-oxidant, therefore, it can be easily be destroyed in a formulation without protection. Thus, it is a good candidate for encapsulation protection. The formulation was as follows:

Capsule formulation	
Petrolatum	133 g
IGI® 941 wax	239 g
50 w/w% Vitamin C aqueous slurry	611 g
Silwet® L77	1 g
Arlacel® P135	13 g
Neodol® 25-3	4 g
Curing solution	
Water	940 g
Neodol® 25-9	50 g
Silwet® L77	10 g

10

Wax and Arlacel® were combined and heated to 65.6°C. 50 w/w% Vitamin C slurry was prepared by partially dissolving Vitamin C in water, followed by the addition of Silwet® L77 to help wet the Vitamin C undissolved particles. Since the premix was a slurry, constant agitation was required. When wax and Arlacel® reached 71.1°C, Vitamin C slurry was slowly added and agitated for 5 minutes. Neodol® 25-3 then was added and mixed for another 10 minutes, followed by adding petrolatum. Agitation was continued for additional 20 minutes. Once the system had reached 65.6°C, spraying commenced. Because these capsules were lighter than water, they floated to the top. Thus, the curing solution was filled up to the rim of collection beaker. As capsules were formed, the bath overflowed and carried the formed capsules to the second collection beaker. The overflow allowed for a new surface for collecting capsules. A make-up curing solution was constantly added to the bath to assist the overflow. The height between nozzle tip and curing bath was set in the range of 5 to 15 cm and the flow rate ranged from 0.95 to 1.5 liter/minute. The average capsule size was about 2500 µm. A concentrated stock of capsules was collected as 35% volume concentration in curing solution. The capsules did not agglomerate on storage.

20

25

15

#### EXAMPLE 11

[00104] Sodium bicarbonate is well known to activate peracid in oral application, however, these components has to be separated in two compartments, which is a very expensive option. This Example demonstrates the utilization of encapsulation to protect sodium bicarbonate from peracid, therefore, the need for two compartments may be eliminated. The formulation was as follows:

Capsule formulation	
Petrolatum	95 g
Sodium bicarbonate	100 g
Arlacel® P135	3 g
Neodol® 25-3	2 g
Curing solution	
Water	940 g
Neodol® 25-9	50 g
Silwet® L77	10 g

[00105] Petrolatum, Arlacel® and Neodol® were mixed and heated to 65.6°C; followed by a slow addition of sodium bicarbonate particles. The resulting mixture was allowed to mix for 1 hour. The pH value was measured before the production of capsules. The process described in Example 5 was used for this example. The capsules' size was between 1000 to 2000  $\mu m$ . A concentrated stock of capsules was collected as 35% volume concentration in curing solution. After 16 hours, only minor pH increase in the bath was observed and no further change in pH for the next 8 hours. The stable pH was the proof that the capsules were stable.

10

15

5

#### **EXAMPLE 12**

[00106] One of the problems with encapsulation has been stability especially with regard to enzyme stability. The main reason for activity loss in the past has been processing temperatures that exceeded levels that are suitable for enzymes to maintain activity. In the past, heating was applied directly by means of a hot plate.

[00107] A method supplying indirect heat was sought. An encapsulation unit was built from stainless steel jacketed beaker. Nozzles were attached at the bottom of jacketed beaker, through which emulsion was sprayed to form encapsulates. At the top of unit openings were made for pressurized air, a mixing shaft, and a pressure release valve. Hoses were attached to upper and lower portions of beaker, through which water from a temperature controlled water bath flowed. This apparatus allowed for consistent indirect heat supply.

25

20

[00108] Capsule formulation was prepared as follows:

> Kraton®, which is a powdery substance, was converted to gel by mixing with mineral oil at 76.7°C. Wax was then added and a homogeneous isotropic liquid (continuous phase) was formed at 62.8°C. The emulsion was then prepared by emulsifying aqueous solution of sorbitol in the continuous phase. The resulting emulsion was a very stable emulsion, even though an emulsifier was absent: it did not phase separate, for 24 hours at 60°C. Capsules were

15

produced using the re-circulating encapsulation unit described in the previous paragraph.

Capsule formulation	
Hydrophobic continuous phase	
Mineral oil	43.83%
1218 wax	9.00%
Kraton® 1650	0.37%
Hydrophilic discontinuous phase	
70% Sorbitol solution	46.80%
Curing solution	
Water	4000g
Neodol® 25-9	20g
Silwet® L-77	20g

5 [00109] The result was discrete, stable, round-shaped capsules, with an average size of about 1500 μm, which did not stick together when they came in contact with one another. A concentrated stock of capsules was collected as 35% volume concentration in curing solution composed of 5% Neodol® 25-9 and 0.5% Silwet® L-77.

#### EXAMPLE 13

[00110] Capsules with the following composition were manufactured:

TABLE 2

Capsule Material Ingredient	Supplier	Weight
Bowax®845	IGI	660 g
Mineral Oil	Penreco	440 g
Concentrated Enzyme*	Genencor	500 g
Sorbitol (70 % solution)	ISP	400 g
Neodol® 25-3	Shell	40 g

\*concentrated in-house (see Example 14)

[00111] Wax and mineral oil were combined and heated to 65.6°C. While mixing, Neodol® 25-3 was added to the system. In a separate vessel, sorbitol and a concentrated enzyme solution were combined and well mixed. This mixture was slowly added to the wax and oil under constant agitation. After all sorbitol/enzyme mixture was added, the system was mixed for an additional

10

15

20

20 minutes to ensure that the internal, discontinuous phase (sorbitol and enzyme) were well emulsified.

[00112] The emulsion was kept in a feeding tank at a temperature of 65.6°C. Agitation in this vessel was performed with an overhead Gifford Wood homogenizer. Once the emulsion was well agitated, a valve at the bottom of the tank was opened and the pump was turned on. The emulsion was recycled through lines so that the system temperature reached ~65.6°C to prevent hardening of the wax. After about 5 minutes, a valve to the nozzle assembly was opened. While most of the emulsion continued through the system, about 5% of the flow was diverted for capsule formation. These capsules were formed and collected in a bath of the following concentration; 92% water, 7.5 % Neodol® 25-9 (HLB 13.1) and 0.5 % Silwet® L-77. These capsules were then removed from the bath and sent for analysis. Enzyme activity was analyzed to yield a 68% recovery. A concentrated stock of capsules was collected as 35% volume concentration in curing solution.

[00113] Enzyme capsules from the concentrated stock of capsules and liquid, non-encapsulated enzyme were then each dosed into a liquid detergent with pH = 12.2. After 3 days in this detergent, 83% enzyme activity remained. A sample of non-encapsulated liquid enzyme in the same type of detergent yielded less than 10% activity remaining after 3 days.

#### **EXAMPLE 14**

- [00114] The following examples (Tables 14A and 14B) provided concentrated, densified and purified enzymes by removing various impurities from the enzyme preparation.
- Enzyme activity of protease and lipase was measured with a standard enzyme using casein and p-nitrophenylvalerate, respectively as a substrate.
  - 1. About 450g of enzyme preparation was placed into Spectra/Por® tubing (8,000 molecular weight cut-off regenerated cellulose).

- 2. The tubing was placed in a beaker containing 3,500g of 70% sorbitol solution and mixed at room temperature.
- 3. After about 24 hours the tubing was removed. Density and activity were measured.

[00115] Continued operation would result in increased density and activity. Also, the sorbitol solution can be replenished to facilitate the process.

[00116] Other preferred operating parameters are as follows:

10

- pH: about 5 to about 10;
- temperature: any temperature that will not harm enzyme activity or stability and that will not cause difficulty of stirring solutions due to high viscosity;
- contact time: a couple of hours to days depending on desired density, activity and impurity level; and

15

- stirring: recommended to facilitate diffusion.

TABLE 14A

Enzyme Preparation	Before Processing		After Processing	
Protease	Activity GU/mg	Density g/ml	Activity GU/g	Density g/ml
Purafect®	3,680	1.08	9,326	1.21
Properase®	4,200	1.08	10,200	1.22
Lipase	Activity LU/mg	Density g/ml	Activity LU/g	Density g/ml
Lipolase®	107	1.02	443	1.24

TABLE 14B

20

25

Enzyme	Before Dialysis (Glycerol)		After Dialysis (Glycerol)	
Preparation				
Protease	Activity GU/mg	Density g/ml	Activity GU/g	Density g/ml
Properase® 1600L	4,300	1.05	7,840	1.20

[00117] As can be seen in Table 14A, activity levels/density levels increased 2.5/1.12 fold (Purafect®), 2.4/1.13 fold (Properase®) and 4.1/1.22 fold (Lipolase®). As such, activity levels at least doubled and density levels increased by at least about 10%.

[00118] Although the illustrative embodiments of the present disclosure have been described herein with reference to the accompanying drawings, it is to be understood that the invention is not limited to those precise embodiments and that various other changes and modifications may be affected therein by one skilled in the art without departing from the scope and spirit of the disclosure.